

## GOV “Flow Enable” CODE ENTRY Instructions

From the Flow Enable display (found as the last entry in Hardware Configuration), the following key sequences must be used:

Use the up arrow key to run the code number up to the given code number.

(After setting the correct code) press F2 then F1 then "+".  
(Flow Enable = F2, F1, "+")

If it is required to disable the flow (not likely), the following sequence must be used.

(After setting the correct code)  
Flow Disable = F2, F1, "-".

You must press these F2, F1, and “+” keys at a certain speed that has been reported to be both s-l-o-w-l-y and q-u-i-c-k-l-y (?). Pressing too quickly (or too slowly) may or may not work! If the sequence does not work, re-enter the given code and press the F2, F1, and “+” keys at a different speed.