

Windows XP COM Port Configuration for use with CPU Terminal Programs

Computers using Windows XP must have the serial port properties configured as outlined in the following instructions. Also, a serial port must be available that is NOT a USB port! Computers having only USB ports must add a serial port by purchasing a PCMCIA card, such as offered by:

Socket Communications, Inc.

37400 Central Court


Newark, CA 94560

Tel 510-744-2782 or fax 510-744-2727


www.socketcom.com or (www.socketcom.com/product/serial_io_pc.htm)


Product # SL0700-004

- 1.) Install the CPU Terminal Program. (all CPU programs will use this port and the port only needs to be configured once)
- 2.) Go to the computers Control Panel, and choose "SYSTEM".
- 3.) At SYSTEM PROPERTIES, choose the "Hardware" tab.
- 4.) At the Hardware page, choose "Device Manager".
- 5.) At Device Manager, highlight the port that you choose to make the COM port for this program. Right click on this, which will take you to Communication Port Properties. Choose the "Driver" tab.
- 6.) Note the "Roll Back Driver" selection on this page. This will be used in the future to return the Com Port driver to the original configuration. This must be done to use the Com Port for anything other than the CPU Terminal Programs. To continue with this Com Port configuration, choose the "Update Driver", and click OK.
- 7.) On the Hardware Update Wizard page, Choose "Install from a list or specific location (Advanced)", and click Next>.
- 8.) Choose "Don't search. I will choose the driver to install." Click Next>.
- 9.) Choose "Have Disk" from this page, then Browse the C:\ drive for any of the CPU programs under Program Files.
- 10.) Once you are looking in a CPU-95 or CPU-2000 file, you will see a "Sernew.inf" file. Highlight this and Open it. Choose "OK" from the "Install from Disk" page.
- 11.) Choose the "Communications Port(ACPI)", and choose Next>.
- 12.) At the Hardware Installation page there may be a warning, choose "Continue Anyway".
- 13.) At the "Completing the Hardware Update Wizard" page, click "Finish". You must now restart your computer to initialize the new Com Port configurations.
- 14.) To return the PC to the previously installed driver, repeat these instructions starting from step #2 through #6. On step 6, choose the "Roll Back Driver" selection.




See information about your computer system, and change settings for hardware, performance, and automatic updates











See information about your computer system, and change settings for hardware, performance, and automatic updates.




See information a










See information about your computer system, and change settings for hardware, performance, and automatic updates



See information about your computer system, and change settings for hardware, performance, and automatic updates

